



## Left hand side

Cord will be placed on the left hand side of the blind



## Right hand side

Cord will be placed on the right hand side of the blind



## Motorised

Blind will be controlled by a motor using a single channel or 15 channel remote (Pre programmed)